

КОНТРОЛЛЕРЫ / ИСПОЛНИТЕЛЬНЫЕ УСТРОЙСТВА / ШЛЮЗЫ

	SA400-FEM-AP	JA200-FEM-AP	SV600-FEM-AP	IN400-FSE-UP	SA100-FEM-UP	SA200-FEM-UP	TA100-FEM-UP	TA200-FEM-UP	JA100-FEM-UP	GW-RS485-FEM	USB - FEM
Система KYMASGARD® 9000											
RFTM-FSE						●	●	●		●	●
RFTM-FSE-ST						●	●	●		●	●
RFTM-VOC-FSE										●	●
RFTM-BW-FSE	●		●		●	●	●	●		●	●
ПРИБОРЫ ДЛЯ ПОМЕЩЕНИЙ Frija											
RTF2 - FSE										●	●
RFTF2 - FSE										●	●
RTF2 - FSE - P			●				●	●		●	●
RFTF2 - FSE - P										●	●
RTF2 - FSE - PT										●	●
RFTF2 - FSE - PT										●	●
RTF2 - FSE - PD2										●	●
RTF2 - FSE - PD5										●	●
RFTF2 - FSE - PD2										●	●
RTF2 - FSE - PD5T										●	●
ОКОННЫЙ КОНТАКТ											
FK - FSE - xx	●	●	●		●	●			●	●	●
НАСТЕННЫЙ ВЫКЛЮЧАТЕЛЬ											
WT - FSE - xx	●		●				●	●		●	●
WT - FSE - Oxx	●						●	●		●	●
WT - FSE - Vxx		●							●	●	●
РУЧНОЙ ПУЛЬТ ДИСТАНЦИОННОГО УПРАВЛЕНИЯ											
HT - FSE - xx	●	●	●		●	●	●	●	●	●	●
НАРУЖНЫЙ ДАТЧИК											
AFTF-HK-FSE										●	●
AWSF-HK-FSE		●							●	●	●

● = оптимально совместимы